




# CHADSON GRANULAR FILTERS SERVICE INSTRUCTION SHEET

DATE: MAY 06 REVISION: B DOC #: 113

PG 1/2


TITLE: INSTALLATION OF CHADSON MULTIPOINT VALVE



STEP 1: Connect Companion Flanges


STEP 2: Cut Stub Pipes to Length.

**NOTE:** THE LENGTH CAN BE DETERMINED ACCORDING TO SITE CONDITIONS. THE BACKWASH VALVE DOES NOT HAVE TO BE CLOSE COUPLED TO THE FILTER AND COULD EVEN BE IN A SEPARATE ROOM.



STEP 3: Solvent Cement Stubs into Multiport Valve.

**CAUTION:** IT IS ESSENTIAL TO REMOVE ALL TRACES OF SOLVENT CEMENT FROM INSIDE VALVE BODY TO PREVENT VALVE PISTONS STICKING.



**STEP 4:** Solvent Cement Stubs into Companion Flanges

**STEP 5:** Tighten Companion Flange Bolts

**NOTE:** DO NOT OVER TIGHTEN.

**STEP 6:** Connect Remaining Pipework to Multiport Valve.

In Australia Class 9 uPVC pipes can be directly solvent cemented into the Multiport Valve. Stub Pipes & Undrilled Companion Flanges are supplied for EXPORT models.

**CAUTION:** IT IS ESSENTIAL TO REMOVE ALL TRACES OF SOLVENT CEMENT FROM INSIDE VALVE BODY TO PREVENT VALVE PISTONS STICKING.

